

PLAYER GUIDE // FORTNITE CONTROL

FORTNITE COMMAND GUIDE

Use the documented runtime controls for rapid fire, movement, and supported Fortnite layouts. In-game updates and remapped controls can change behavior.

• HARDWARE SIGNAL VERIFIED



CONFIRM YOUR CONTROLLER

01

Complete PS5 controller customized by Silent Modz.

02

Base edition: runtime controls only; no rear-button programming.

03

D-pad Up is the feature-access control used on these commands.

QUICK START // BUTTON MAP



RAPID FIRE



TAP TWICE: BURST



JUMP



CROUCH

RUNTIME COMMANDS // COMBAT

Fire and movement controls

Use the base commands during play. Confirmation behavior can vary by controller revision.

01 // RAPID FIRE

Repeat the R2 fire input

Tap once to enable the documented rapid-fire mode for compatible weapons.



TAP ONCE

02 // THREE-ROUND BURST

Three shots per trigger pull

Tap the same command twice to select the burst behavior.



TAP TWICE

03 // CROUCH

Repeat the R3 input

Use only when the active Fortnite layout maps crouch to R3.



TOGGLE

04 // JUMP

Choose one of two jump behaviors

Tap once to pause jumping while aiming down sights. Tap twice to continue jumping while aiming.



ONCE / TWICE

RUNTIME COMMANDS // SUPPORT

Auto Run and Aim Assist input

These commands reproduce controller inputs; they cannot override Fortnite settings, updates, or server rules.

05 // AUTO RUN

Sustain the L3 movement input

Toggle the documented run behavior. Results depend on movement and sprint settings.



TOGGLE

06 // AIM ASSIST INPUT

Repeat the L2 input

This feature only repeats the documented input. Effectiveness depends on the current Fortnite version, controller settings, and layout.



TOGGLE

07 // CROUCH OR JUMP

Select one movement loop

The source system treats Crouch and Jump as mutually exclusive; enabling one disables the other.

- Confirm R3 still means crouch before use.
- Retest after major game updates.



FINAL CHECK // BASE EDITION

Know what this controller supports

This guide intentionally includes only the runtime controls documented for the Base edition.

BASE HARDWARE BOUNDARY

This manual does not add four rear controls, layout programming, turbo rear buttons, or a central rear setup function. Those belong to the Fortnite Pro product only.

GAME UPDATE WARNING

Fortnite can change control layouts and input behavior. Confirm the current in-game button assignments before relying on any command.

NO PERFORMANCE GUARANTEE

The controller repeats supported inputs; it does not guarantee an advantage, accuracy improvement, win rate, or compatibility with every update.

QUICK RECOVERY

If a movement loop is not behaving as expected, disable it with the same command, verify the active in-game layout, and test again in a private environment.

NEED A HAND?

Send us your order number and controller version.

[SILENTMODZ.COM/CUSTOMER-HELP](https://silentmodz.com/customer-help)