

STANDARD CONTROLLER // CONNECTION

Connect. Confirm. Play.

A quick-start guide for Silent Modz custom Xbox Wireless Controllers on console, Windows PC, and supported mobile devices.

CONTROLLER SIGNAL MAP



XBOX / POWER BUTTON
Press to power on



01 // XBOX

Xbox Console

Use Xbox Wireless pairing or a compatible USB data cable.



02 // WINDOWS

Windows PC


Connect with Bluetooth, Xbox Wireless Adapter, or USB.



03 // MOBILE

iOS / Android

Bluetooth connection for supported devices, apps, and games.



04 // USB

Wired Play

Use a compatible data cable for console or Windows PC.

XBOX BUTTON SIGNAL

SOLID = CONNECTED


Rapid flashing means the controller is searching in pairing mode.

XBOX WIRELESS // CONSOLE

Pair With Your Xbox.

The console Pair button location varies by Xbox model. Look for the small Pair symbol/button on the console.

TOP EDGE // BUTTON LOCATION



PAIR BUTTON

USB-C PORT

01 // POWER ON

Wake the controller.

Press the Xbox button. If it stays solid, the controller is already connected.

02 // START CONSOLE PAIRING

Make the console discoverable.

Press and release the Pair button on the Xbox console. Its pairing light will flash.

03 // HOLD CONTROLLER PAIR

Send the controller signal.

Within 20 seconds, hold the controller Pair button for a few seconds until the Xbox button flashes rapidly.

04 // CONFIRM CONNECTION

Watch for a solid Xbox button.

When the Xbox button stops flashing and stays lit, the controller is connected and ready.

WIRED CONNECTION // QUICK TEST

Use a compatible USB data cable between controller and console.

Charge-only cables may provide power but cannot carry controller input.

CONTROLLER > USB DATA CABLE > XBOX

WINDOWS // THREE CONNECTION PATHS

Choose Your PC Signal.

Bluetooth requires a Bluetooth-capable Xbox Wireless Controller and Windows device. Menu wording can vary by Windows version.

01 // OPEN BLUETOOTH SETTINGS

Start a Windows device scan.

Open Settings > Bluetooth & devices > Add device > Bluetooth. Keep this screen open.

02 // ENTER PAIRING MODE


Power on, then hold Pair.

Press the Xbox button, then hold the controller Pair button for a few seconds until the Xbox button flashes rapidly.

03 // SELECT THE CONTROLLER

Complete the Windows connection.


Choose Xbox Wireless Controller from the device list. Connection is complete when the Xbox button stays lit.



USB WIRED

Plug in a compatible USB data cable.

Windows should recognize the controller automatically.
Try another USB port or cable if it only powers on.



XBOX ADAPTER

Pair with an Xbox Wireless Adapter.

Press the adapter Pair button, then hold the controller Pair button. Wait for both connection lights to stay lit.



BLUETOOTH // MOBILE DEVICES

Pair. Launch. Play.

Controller support varies by device, operating system, app, and game. Bluetooth-capable controller hardware is required.

01 // IPHONE / IPAD

Open Apple Bluetooth settings.

Power on the controller, hold Pair for a few seconds, then open Settings > Bluetooth and select Xbox Wireless Controller.

02 // ANDROID

Open the device pairing screen.

Power on, hold Pair, then open Settings > Connected devices > Pair new device and select the controller.

+
XBOX BUTTON > HOLD PAIR > DEVICE BLUETOOTH > SELECT CONTROLLER

CONNECTION RECOVERY // RUN IN ORDER

01 CHECK POWER

Install fresh AA batteries or charge a supported rechargeable pack, then retry near the device.

02 FORGET + REPAIR

Remove the saved Xbox Wireless Controller entry, restart Bluetooth, and pair again.

03 TEST USB DATA

Use a known data-capable cable and another USB port to separate wireless issues from controller issues.

04 UPDATE + VERIFY

Update controller firmware with Xbox Accessories, then test a supported game or app.

BATTERY + SUPPORT BOUNDARY

Do not mix old/new batteries or battery types. USB-C does not recharge AA batteries. Custom shells and finishes do not change standard pairing unless the product listing says otherwise.

NEED HELP?
[SILENTMODZ.COM/CUSTOMER-HELP](https://silentmodz.com/customer-help)